

iWorkCase Nutzungshinweise

Herzlichen Glückwunsch zum Erwerb des iWorkCase. Wir freuen uns Sie in der iWorkCase Community begrüßen zu dürfen. Bevor Sie das iWorkCase nutzen, müssen wir Sie noch auf folgende Dinge hinweisen.

Mindestvoraussetzungen für Kugelköpfe und Stative:

Tragfähigkeit des genutzten Stativs: mindestens 10 kg

Tragfähigkeit des genutzten Kugelkopfs: mindestens 18 kg

Für die korrekte Nutzung des iWorkCase ist der Nutzer verantwortlich. Das iWorkCase tragende Stativ muss sicher auf festem Untergrund positioniert werden. Zur Stabilisierung muss die Stativmittelsäule mit zusätzlichem Gewicht belastet werden. Sämtliche Schrauben des Kugelkopfes müssen fest zuge dreht werden um ein verdrehen des Kugelkopfes zu verhindern. Prüfen Sie bitte ob sich das iWorkCase nach festziehen der Kugelkopfschrauben verdrehen lässt. Wenn das der Fall ist müssen die Schrauben noch fester angezogen werden.

Achten Sie bei windigen Bedingungen darauf, dass der Kofferdeckel in Windrichtung positioniert wird.

Das iWorkCase richtig packen

Um Beschädigungen des Notebooks zu vermeiden achten Sie bitte darauf, die folgende Packreihenfolge einzuhalten.

1. Geschlossenes Notebook in das Inlay legen
2. Gefaltetes iWorkCase Dunkeltuch auf das geschlossene Notebook legen (vorgegebene Dunkeltuch Faltung ist einzuhalten, dass sich der Deckel des iWorkCase gut schließen lässt.)
3. Zusammengeklappten Sichtschutz auf das Dunkeltuch legen.
4. Deckel des iWorkCase schließen. Eine leicht erhöhte Schließkraft lässt sich leider nicht vermeiden, führt jedoch nicht zu Beschädigungen der im iWorkCase untergebrachten Geräte.

Wenn Sie diese Reihenfolge einhalten ist Ihr Notebook sicher im iWorkCase untergebracht und vor Beschädigungen geschützt.

Die iWorkCase **Lüftungseinheit** stellt sicher, dass das Notebook im iWorkCase ausreichend belüftet wird und nicht überhitzt. Der Betrieb eines Notebooks ohne den Einsatz der Lüftungseinheit ist im iWorkCase nicht zulässig. Stellen Sie jederzeit sicher, dass das Notebook während des Betriebs auf der Lüftungseinheit aufliegt. Zum Transport wird die Lüftungseinheit an den Klettverschluss auf der

Innenseite des iWorkCase Deckels angebracht. Kommt das Notebook zum Einsatz entnehmen Sie die Lüftungseinheit aus dem Deckel und positionieren diese in den langen Schlitz am hinteren Ende des Inlay. Das Notebook liegt dann auf den drei Erhebungen der Lüftungseinheit auf. Falls Sie Ihre Lüftungseinheit verlieren wenden Sie sich bitte an info@iworkcase.com.

Das **iWorkCase Dunkeltuch** dient nicht nur zur Abdunkelung des Monitors, sondern auch dem Schutz des Notebooks während des Transports und dem Schutz vor starker Sonneneinstrahlung. Damit das iWorkCase einfach verschlossen werden kann und Beschädigungen des Notebooks vermieden werden, ist darauf zu achten, dass das Dunkeltuch richtig gefaltet wird. Beachten Sie hierzu bitte unsere separate **Dunkeltuch Faltanleitung**.

Der **Card Reader Platz** im iWorkCase ist für die Nutzung mit dem führenden Sandisk Fire Wire 800 Card Reader ausgelegt.

Hinweis zur Lagerung der iWorkCase Inlays:

Dieser Hinweis ist nur dann relevant, wenn das Inlay aus dem iWorkcase genommen wird um es außerhalb des iWorkCase zu lagern (z.B. wenn Sie mehrere Inlays nutzen).

Die iWorkCase Inlays dürfen ausschließlich liegend (waagrecht) gelagert werden. Hierdurch wird vermieden, dass der Schaumstoff sich verzieht und die Funktionalität des Inlays beeinträchtigt wird. Nutzen Sie bitte die original Inlay Kartons für den Transport und die Lagerung der iWorkCase Inlays. Hierdurch können Beschädigungen vermieden werden.



Bedienungsanleitung

Unsere Video Bedienungsanleitung finden Sie auf www.iWorkCase.com

Info: Alle iWorkCase Dokumente können im Download Bereich auf www.iworkcase.com jederzeit erneut abgerufen werden.

Die meierSupport GbR haftet nicht für Schäden, die durch unsachgemäßen Einsatz des iWorkCase entstehen.

iWorkCase Product Information

Thank you for buying the iWorkCase. We are happy to welcome you to the iWorkCase community. Before you start using the iWorkCase, please read the following instructions and information.

Product Usage Prerequisites:

Minimum load capacity of the used tripod: 10 kg
Minimum load capacity of the used ballhead: 18 kg

Please take into account: You are responsible for the correct use of the iWorkCase. The meierSupport GbR is not responsible for misuse. You must position your tripod safely on the ground, with additional weight at your tripod center column. Fix your tripod head properly. After mounting the iWorkCase on the tripod ballhead, please check whether the iWorkCase can be moved. If you can move it, the screws on your ballhead must be tightened more. In windy conditions, be aware of wind gusts. We recommend to align your workstation with the top cover of the case to the wind direction.

How to pack your iWorkCase

Please follow this packing sequence to avoid damages to your notebook.

1. Place your closed notebook into the inlay.
2. Place your folded iWorkCase dark cloth onto the closed notebook. Put your folded iWorkCase sunshield rag on the closed notebook (please follow the folding instructions, otherwise the case lid will not close).
3. Place the folded sunshield unit directly on the dark cloth.
4. Close the lid of the iWorkCase.
There is always a slightly increased closing force. This is normal. This will not damage the gadgets stored in the iWorkCase.

If you follow this sequence, your notebook is stored safely in the iWorkCase.

The iWorkCase **air circulation unit** allows proper air flow, which prevents your notebook from overheating. Do not use your notebook without proper air circulation! Improper air circulation will cause severe damage to your notebook! Before turning on your notebook, it must be placed on the air circulation unit. For



transportation, attach the unit to the velcro strip on the inside of the iWorkCase lid.

Before you start working with your notebook in the case:

Remove the air circulation unit from the lid and place it in the long slot on the back of the inlay. If done properly, the notebook will now rest on the three bumps of the unit. If you lose your air circulation unit, please contact info@iworkcase.com.

The iWorkCase **dark cloth** is not only used for darkening the monitor, it also protects the notebook from strong sunlight, as well as, during transportation.

To avoid damages to your notebook and ease in the closing of your iWorkCase, make sure your dark cloth is folded correctly. As per instructions noted. Our separate dark cloth folding instructions shows you how to fold correctly.

The **Card Reader section** in the inlay is optimized for the commonly used "Sandisk Fire Wire 800 card reader."

Storage information for iWorkCase Inlays

This information is only relevant, if you take your inlay out of the iWorkCase to store it outside of the iWorkCase (e.g. if you use more than one iWorkCase Inlay)

The iWorkCase Inlays have to be stored in a lying position. This position will prevent shape distortion of the foam. Please ensure this storing position for a long life of your inlay. Please use the original inlay carton for storage and transportation of the inlays. This will provide the optimal protection of your inlays.



User manual

You can find our video user manual on www.iWorkCase.com

Additional information

All iWorkCase documents are available in the download section on www.iWorkCase.com

The meierSupport GbR is not liable for damages caused by improper use of the iWorkCase.